



TECHNICAL DATA SHEET

RASCOflex AY-RE (Retarder)

RASCOflex AY-RE is an ancillary product for use in conjunction with all RASCOflex acrylic grouts.

USE

RASCOflex AY-RE is used whenever the standard gel time for RASCOflex AY grouts needs to be extended.

FEATURES

- may be used with all RASCOflex AY formulations
- suitable for potable water applications
- must only be added to A component

APPROVALS

- REACh-assessed exposure scenarios: water contact, periodic inhalation, application
- REACh-tested raw materials, classed as harmless



TECHNICAL/PHYSICAL DATA

Supplied form	liquid
Material colour	yellow/greenish
Container type	canister
Container size	5 ltr
Dichte (DIN EN ISO 2811)	1,02 kg/ltr (± 0,05)
Hazardous goods/ADR	none
Viskosität bei 23° C (DIN EN ISO 3219)	4 - 12 mPas
Application temperature	See technical data sheet of relevant RASCOflex acrylic system
Storage/shelf life	12 months in original container, from +5° C to +25° C, in dry conditions

APPLICATION

RASCOflex AY-RE shall always be added to the A component. To guarantee controlled polymerisation, the proportion of retarder shall not exceed max. 8% (by volume). Very thorough mixing is required after addition of RASCOflex AY-RE. Use of a drill with mixing paddle attachment is recommended. The action of RASCOflex AY-RE is temperature-dependent and shall be determined for each specific application on the basis of preliminary tests. In addition to the ambient and material temperature, attention shall also be paid to the building fabric temperature.

GENERAL GUIDELINE

Unused retarded A components shall be clearly marked with precise details of the proportions added. Particular care is required when retarding as an excessive dosage of RASCOflex AY-RE may prevent the material from polymerizing! Up to 60-minute retardation is feasible. Non-binding rule of thumb: for retarded material, an approx. 7°C higher temperature will halve the gel time, while an approx. 7°C lower temperature will double the gel time. RASCOflex AY-RE freezes when stored at sub-zero temperatures. However, frozen RASCOflex AY-RE Retarder may still be used as normal after slow thawing.

SAFETY NOTICE

Suitable protective clothing, gloves and goggles shall be worn. An eyewash bottle shall be kept at hand. For further details, please consult safety data sheet.

SUPPLY/ADDITIVE

Item no.	Product	Container	Contents
1101.3011.001	RASCOflex AY-RE Retarder	canister	5 ltr

LEGAL NOTICE: The information provided on the use and application of our products in this technical data sheet is based on the present state of our knowledge. The customer shall bear sole responsibility for the proper specification, application and use of the products in line with the intended purpose, project-specific conditions and external actions. The most recent technical data sheet shall apply. The current technical data sheets are available at www.rascor.com. Our General Terms of Business shall form an integral part of this technical data sheet.

Rascor International Ltd.
Gewerbestrasse 4
CH-8162 Steinmaur / Switzerland
Phone: +41 (0)44 857 11 11
Fax: +41 (0)44 857 11 00
www.rascor.com